



writeINFINITY (dry erase paint)

care and maintenance instructions

After the installation of your new Write Walls dry erase coated surface, please follow the following suggested cleaning and maintenance instructions for the optimal long term performance of your surface:

recommended supplies

We have found all dry erase markers perform when erased within 48 hours. If you have the need to leave markers on the wall surface you can do so for extended periods of time using: Expo Low Odor Bullet #82074

Foam, Felt or Micro Fiber cloth type erasers should be utilized for optimal performance.

general maintenance

All wall surfaces should be cleaned once per week with water and/or dry erase cleaner to ensure long term performance. The use of a Micro Fiber cloth is ideal when cleaning a wall surface.

Mr. Clean Magic Eraser products can be used if necessary. All cleaning products should be rinsed clean from the surface with fresh clean water after use.

permanent marker

Should permanent marker be used on the surface we recommend going over this area with an Expo Bold marker, erasing and then cleaning the balance with the use of alcohol swabs. We cannot guarantee the full removal of a permanent marker as time plays a key role in how well this type of marker can be removed from a surface.

All cleaning products should be rinsed clean from the surface with fresh clean water after use.